



Instructions

Remove the protective foil from the wine bottle with the Insta-pull foil cutter.
Place the foil cutter over the top of the foil and squeeze while making a 1/2 circle turn to remove foil.
If bottle has a flange top with wax covering the cork, remove the wax with a knife before using.



1



Pull the lever back to set the gear.

2



Place the Insta-pull over the top of the bottle and grip firmly as shown.

3



Pull the handle up and down to enter the cork.

4



Pull the cork out, by moving the handle up and back as shown.

5



To release the cork, hold the grips and move the handle up and down firmly to close the Insta-pull.

This will reset the gear



The Gear will CLICK when reset.

6



Now pull the handle up and the cork will unscrew and drop out.

7

Care Instructions:

- 1) The Insta-pull is designed to quickly remove corks, however it is best to use the Insta-pull slowly since many corks are fragile.
- 2) Clean with a damp cloth. Never submerge in water, this will damage the mechanism.
- 3) Should you break the non-stick coated worm. An extra worm is included. You may replace the worm by unscrewing the top cap, removing the old worm, and inserting the replacement worm in it's place. Screw the top cap on firmly before use.

